

Filling Instructions

for Plastic Cartridges
M6T05 & M6T10



CCELL[®]
OFFICIAL DISTRIBUTOR

Filling Instructions

1. Insert a blunt tipped needle into the space between the airway + the outer wall of the cartridge and fill with 0.5ml of oil.

- Cartridge must be **upright** when filling the reservoir with oil
- Recommended Fill Temperature **Between 90° - 130° F**
- **Do not fill** into the middle post, or severe leaks will occur.
- **Do not** overfill or allow oil to enter center way
- + **Fill up to Silver Band**
- + **Do not** fill past the 4 holes on the middle post

Caution

- If overfilled when press fitting the mouthpiece, oil will overflow and drip down into the cartridge. Wipe with alcohol immediately.
- If overfilled, cartridges exposed to high temperatures than during filling, will cause oil in cartridge to expand and leak.
- If **ANY** leaks are experienced, for any cartridges filled after leaking cartridge, flip the cartridge upside down after filling to purge more air.
- **ANY OIL RESIDUE** left in the area of the cartridge where the tip is pressed on may cause the tip to pop back up.
- Warranty is void if filling instructions are not followed.

2. Immediately after filling, insert + press the mouthpiece until fully sealed. Mechanical assistance, such as an arbor press or channel lock pliers are required to fully seal the mouthpiece.



- **Do not** leave any silicone caps on tip or base of cart when capping.
- If using pliers, cushion jaws with cloth or tape to prevent damage.
- Failure to insert the mouthpiece immediately may cause leakage.
- **Do not** flip cartridge upside down, CCELLs must remain upright.
- If cleaning/wiping down cart:
Use diluted mixture of 50% or less alcohol, and water

Usage

Please wait at least 30 minutes before using to allow the atomizer to saturate for the best vapor production.



Visit www.kushsupplyco.com/vape-support
or call **888.920.5874** to learn more.