

Filling Instructions

for Glass Compression Carts

TH205-Y & TH210-Y



Filling Instructions

1. Insert a blunt tipped needle into the space between the airway + the outer wall of the cartridge and fill with 0.5mL/1.0mL of oil.

- Cartridge must be upright when filling the reservoir with oil
- Recommended Fill Temperature **Between 90° - 130° F**
- **Do not fill** into the middle post, or severe leaks will occur.
- **Do not** overfill or allow oil to enter center way

2. Immediately after filling, insert + press the mouthpiece until fully sealed. Mechanical assistance, such as an arbor press are required to fully seal the mouthpiece.

- **Recommended: Use Kush Compression Cart Arbor Press**
- If not using the TH2-Y Kush Arbor Press, cushion press with cloth or tape to prevent damage.
- Do not leave any silicone caps on tip or base of cart when capping.
- Failure to insert and compress the mouthpiece immediately may cause leakage.
- **Do not** flip cartridge upside down, CCELLs must remain upright.
- If cleaning/wiping down cart: Use diluted mixture of 50% or less alcohol, and water

Caution

- If overfilled when compressing the mouthpiece, oil will overflow and drip down into the cartridge. Wipe with alcohol immediately.
- If overfilled, cartridges exposed to high temperatures than during filling, will cause oil in cartridge to expand and leak.
- When using an arbor press, if not using the Custom Kush Press, do not apply too much pressure when compressing. This may cause fissures in the glass.
- Make sure tip is placed on straight before pressing to ensure the tip is not crooked after compressing to the cart.
- Warranty is void if filling instructions are not followed

Usage

Please wait at least 30 minutes before using to allow the atomizer to saturate for the best vapor production.

